

## COMPUTER UPDATE NOTICE

**SUBJECT: IQ-900 ZEN WATCH UPDATE**

### **FIRMWARE UPDATE RELEASE DETAILS**

**For IQ-900 ZEN Watch Dive Computers to version 1D**

#### **EXPLANATION**

In response to input received from owners and users of the IQ-900 ZEN, TUSA has corrected or modified the following items to improve the IQ-900 ZEN's operation:

- Corrected premature auto reset of FO2 from a Nitrox setting to an Air setting. This occurred without user action when Watch Mode was temporarily accessed after FO2 was set for Nitrox.
- Changed the No Deco Safety Stop Depth from 4.5M to 5M (metric units). This was requested to be in agreement with local training guidelines.

#### **UPDATE PROCESS**

Units affected are the IQ-900 ZEN model containing earlier versions of firmware. To check your computers firmware version, please consult the owner's manual.

In the event that you have experienced any of the above, or you want to be sure they don't occur, you can upgrade your IQ-900 ZEN's firmware (operating software program) to newly released revision 1D using the IQ-900 ZEN Firmware Update program (version 2.0.1). The IQ-900-030 ZEN Series USB cable is required. There is no need to return the unit to TUSA.

***The update program with download instructions is available at [www.tusa.com](http://www.tusa.com) under the Support Section  
Or directly at this [link](#) (.zip file, 14MB)***

Should you have any questions, please contact your Authorized TUSA Dealer, or TUSA Customer Service by calling 800-482-2282 (8AM -5PM, PST Monday - Friday) or send an email to [info@tusa.com](mailto:info@tusa.com).

## COMPUTER UPDATE NOTICE

**SUBJECT: IQ-950 ZEN AIR WATCH UPDATE**

### **FIRMWARE UPDATE RELEASE DETAILS**

**For IQ-950 ZEN AIR Dive Computers to version 1B**

#### **EXPLANATION**

In response to input received from owners and users of the IQ-950 ZEN AIR, TUSA has corrected or modified the following items to improve the IQ-950 ZEN AIR's operation:

- Added EEPROM (memory) protection in the operating code to prevent data stored in the viewable Log from changing. This occurred after conducting NORM dives when data was first displayed in the Log as No Deco then upon access later it was displayed as being Deco and GAUG.
- Changed the No Deco Safety Stop Depth from 4.5M to 5M (metric units). This was requested to be in agreement with local training guidelines.

#### **UPDATE PROCESS**

Units affected are the IQ-950 ZEN AIR model containing earlier versions of firmware.

In the event that you have experienced any of the above, or you want to be sure they don't occur, you can update your IQ-950 ZEN AIR's firmware (operating software program) to newly released revision 1B using the IQ-950 ZEN AIR Firmware Update program (version 2.0.0). The IQ-900-030 ZEN Series USB cable is required. There is no need to return the unit to TUSA.

***The update program with download instructions is available at [www.tusa.com](http://www.tusa.com) under the Support Section  
Or directly at this [link](#) (.zip file, 14MB)***

Should you have any questions, please contact your Authorized TUSA Dealer, or TUSA Customer Service by calling 800-482-2282 (8AM -5PM, PST Monday - Friday) or send an email to [info@tusa.com](mailto:info@tusa.com).